



1. Install one ten foot stick out of ground at service pole. Provide the additional following for BCES to install:
  1. 2 x Ten Foot Stick 3" Schedule 80 Gray PVC (for a total of 3 10' sticks out of ground)
  2. 4 x 3" Conduit Straps
  3. 1 x 3" PVC Weatherhead
2. Warning Underground Plastic Marker should be placed in ditch one foot above underground pipe, provided by BCES.
3. This applies to ALL underground services.

K:\Front Office\BCES Service Cust Reference Sheets\Underground Service with Pole Mount Transformer.pdf

Updated 8/5/2021